

Introduction

The Silent Alarm (SW-433) is designed to work with all Skylink sensors that incorporate the rolling code technology. This alarm can work with as many as 15 different sensors. For instance, it can work with the Security System Control Panel, Temperature Sensor, Smoke Alarm Sensor, Vibration Sensor, Flood Sensor, Door/Window Sensor are activated. They will

transmit a signal to the Silent Alarm, and the appliance that has been plugged into the silent alarm will be turned on and off for approximately 15 seconds. If a lamp is plugged into the Silent Alarm, the light will flash so that it can notify the hearing impaired. (or you may plug in a radio to warn the visually impaired)

1. In order for the Silent Alarm to recognize different transmitters, they must first be "learned" to the Silent Alarm.
2. Plug in the Silent Alarm to an electrical outlet (its red LED light will go on). Plug in an appliance (i.e. light, radio, maximum 1200 watts) to the outlet of the Silent Alarm.
3. Turn on the appliance that is plugged into the Silent Alarm. Turn on the Silent Alarm by pressing the "ON/OFF" button. The appliance should be on after the "ON/OFF" button is pressed. If you press the "ON/OFF" button again, the appliance will be turned off.
4. With the Silent Alarm plugged in, press and hold the "SET" button on the unit (its red LED light will flash). Simultaneously activate the sensor that you want to program to the silent alarm until the red LED light on the silent alarm stops flashing indicating it has learned the code.
5. Test the sensor by activating it while the Silent Alarm and the appliance are plugged in. The appliance will turn on and off for approximately 15 seconds. If the appliance that you plugged in does not turn on and off, repeat the above procedures .



Warranty

If, within one year from date of purchase, this product should become defective, due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

The Remote Control is approved by the FCC and it complies with Part 15 of the FCC Rules. Its operation is subject to the following two conditions :

1. This device may not cause harmful interference.

2. This device must accept any interference that may cause undesired operation.

FCC

WARNING: Changes or modifications to this unit not expressly approved by the party responsible of compliance could void the user's authority to operate the equipment.

NOTE

If you would like to order Skylink's product or have difficulty getting them to work, please :


1. visit our website FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com, or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.
fax: 1-800-286-1320

CUSTOMER SERVICE
17 Sheard Avenue, Brampton,
Ontario, Canada L6Y 1J3
Email: support@skylinkhome.com
<http://www.skylinkhome.com>
P/N. 101A091-001
US Patent 6243000B1
©2005 SKYLINK GROUP

Skylink will not be held liable or responsible for any misuse or application of this product other than for its intended use.



SILENT ALARM USER'S INSTRUCTIONS (Model SW-433)



® are registered trademarks of their respective corporations